

# SONY

## Wireless Stereo Headset Casque stéréo sans fil

Operating Instructions  
Mode d'emploi  
Manual de instrucciones  
使用説明書  
사용 설명서  
Инструкция по эксплуатации  
تعليمات التشغيل  
Bedienungsanleitung  
Istruzioni per l'uso

Gebruiksaanwijzing  
Instruções de operação  
Betjeningsvejledning  
Käyttöohjeet  
Bruksanvisning  
Bruksanvisning  
Kezelési útmutató  
Návod k použití

Návod na obsluhu  
Инструкция за експлоатация  
Instrucțiuni de utilizare  
Navodila za uporabo  
Upute za uporabu  
Uputstva za korišćenje  
Οδηγίες λειτουργίας  
Інструкції з експлуатації

WF-C500

Model, Modèle, Modelo, 型號: YY2952

©2021 Sony Corporation  
Printed in Vietnam / Imprimé en Vietnam  
5-030-787-11(1)



\* 5 0 3 0 7 8 7 1 1 \* (1)

### 1

1. Place the headset in the charging case. Close the case. Connect the case to a USB-C charging cable. The case will charge the headset. The charging time is approximately 3 hours.

### 2

2. Insert the earbuds into the ear. The earbuds are labeled 'M' (Medium) and 'LL' (Left) and 'SS' (Right).

### 3

3. Download the Sony Headphones Connect app from the app store. The app will guide you through the pairing process. The app shows the headset as 'WF-C500' and the connection is confirmed as 'Bluetooth connected'.

### 4

4. Use the headset to listen to music. The user can use touch controls on the earbuds to play/pause music, skip tracks, and adjust volume. The app also shows volume control options.

