





H A Y L O U

# **HAYLOU** MoriPods ANC

ANC True Wireless Earbuds

User Manual

# Overview



## How to Wear




Gently insert the earbud into the ear canal, adjust the earbud to the most comfortable wearing state. It is recommended to choose suitable size of ear tips to ensure ANC effect.



When calling, adjust Mic towards mouth to gain better talking experience.

## How to Charge

For first time use, please remove the isolation film on the charging contacts of both earbuds. Then fully charge the charging case and earbuds.




Plug in the charging cable to charge the earbuds and the charging case at the same time. The charging indicator light will be solid white when the charging case is not fully charged. The indicator light goes out after fully charged.



## Power-on

Take out to auto power on when the earbuds are in case.



## Power-off


The earbuds will auto power off when put in the charging case.



## How to Pair

Take two earbuds out from the charging case simultaneously, then open device Bluetooth and search for "Haylou MoriPods ANC", finally click it to complete the connection.

Put the earbuds back to the charging case and repeat the above operation if the connection fails. After the first connection, the earbuds can be automatically connected to the last paired device (Bluetooth needs to be turned on).



**Switch between mono and stereo mode:** It is stereo mode after two earbuds are successfully connected. Put one back into the case to power off, the other will enter mono mode. Or pick it up again to resume stereo mode.

# Functions



- **Long touch MFB button for 1.5s**  
Play/pause music
- **Double touch left MFB button**  
Skip track backward
- **Double touch right MFB button**  
Skip track forward
- **Long touch MFB button for 1.5s**  
Answer/hang up
- **Triple touch right MFB button**  
Switch among noise cancellation, standard and transparent modes
- **Triple touch left MFB button**  
Turn on/off low latency mode

## Answer the Second Call

When there is a new incoming call during a call, long touch the MFB button for 1.5s to hold the previous call and answer the second call, then double touch the MFB button to switch the call, hold the current call, switch to the previous call, and then long touch the MFB button for 1.5s to hang up the current call and answer the call on hold.

## Factory Setting

1. Put the earbuds back into the charging case and keep the charging case fully charged. Then long touch the earbuds MFB buttons for 10s until the earbuds LEDs flash 3 times;
2. Clear phone pairing record and complete the connection again.

### **Common abnormal:**

1. One of the earbuds is mute:  
Try to put the mute earbud into the charging case and then take it out;  
If the problem is still not solved after the above operation, try the reset steps;
2. The earbud cannot be charged:  
Check whether the charging case has sufficient power;  
Wipe the charging contacts with a dry cloth or cotton swab;
3. The earbud cannot automatically disconnect from the mobile phone;  
Check whether the charging case has sufficient power. The earbud will not power off if the case is out of power and will not disconnect from the mobile phone.



# Package List

Earbuds, charging case, charging cable, user manual.

Product model: Haylou MoriPods ANC

## Basic Parameters(earbuds)

Operation range: 10m (open space with no obstacle)

Battery capacity: 43mAh(single earbud)

Charging time: approx. 1.5hr

Talk time: approx. 4.5hr

Standby time: approx. 60hr

Input parameter: 5V = 43mA

Battery type: li-ion

Bluetooth version: V5.2

## Basic Parameters(charging case)

Input parameter: 5V = 500mA

Output parameter: 5V = 100mA

Charging time: approx. 2hr

Battery capacity: 310mAh

Battery type: li-ion



FCC ID:2AMQ6-MORIPODSANC

# Caveats

## Warning

1. Do not disassemble, repair or modify the product for any reason, as this may cause fire or even completely destroy the product.
2. Do not expose the product to environments where the temperature is too low or too high (below 0°C or above 45°C).
3. Keep the indicators away from the eyes of children and animals while using the earphones.
4. Do not use this product during thunderstorms. Thunderstorms may cause the product to malfunction and increase the risk of electric shocks.
5. Do not wipe and clean the earphones or their case with alcohol or other volatile liquids.
6. Avoid any contact with liquids.

## Note

1. Please read this user manual carefully before using the product and please properly store it.
2. When using for the first time, please fully charge this product.
3. Please charge the product, in case it has not been used over two weeks.

4. Please use certificated charger.
5. Do not wear earphones for a long term to protect your hearing.
6. Do not wear earphones in any situations with potential risks as wearing them may reduce your perception to the outside world.

### **FCC Requirement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference;
2. This device must accept any interference received, including interference that may cause undesired operation.

### **Daily maintenance**

Please do not shower with earbuds. Do not wear them in rainy day. Do not leave them in washing machine or other extreme situations. Clean them with dry cloth.

2. Defects or physical damages caused by leaking or dropping off.
3. Damages caused by act of God.  
Supposing your item is within any damages or defects except the above circumstances, please return to us or your distributor for free repairing.

Manufacturer: Dongguan Liesheng Electronic Co., Ltd.

Address: Room 401-410, Building 1, No.  
86 Hongtu Road, Nancheng District,  
Dongguan City, Guangdong, China